

# decotric MC Instant Adhesive Vinyl/Textile - instant decotric MC Vinyl- und Textilkleber Instant

High-quality, fast-dissolving methylcellulose Adhesive

**Instructions for use:** *decotric MC Instant Adhesive Vinyl/Textile* is suited for vinyl and vinyl foam wallpapers, all kinds of textile, woven and paper-backed fibreglass cloths and other heavy wallpapers.

**Technical specifications:**

Components:	methyl cellulose, emulsion powder
Density:	0.45 g/cm <sup>3</sup>
pH-value:	approx. 8
Solubility:	ready to use in approx. 3 minutes
Usage:	approx. 200-300 ml/m <sup>2</sup>

**Surface preparation:** The surface must be dry, firm and free of dust and grease. Remove old, peeling wallpapers and distemper paints using *decotric Wallpaper Remover*. Make good cracks and holes using *decofill Interior* or *decomur Super Bonding Filler*. Prime highly absorbent, sanding and chalking surfaces with *decotric deeply Penetrating Primer – Solvent Free*.

Water-soluble contaminations in the surface, which could show through when wallpapered over, should be isolated using *decotric Insulating Spray*.

We recommend applying a sub-coat of *decotric Wallpaper Primer - white* before hanging highly translucent wallpapers and where surfaces are highly contrasting. To make a subsequent change of wallpaper easier, we recommend priming the surface first with *decotric Wallpaper Base Primer 'Tapeten-Wechselgrund'*, especially where washable wallpapers are used.

**Application:** Stirring vigorously, sprinkle *decotric MC Instant Adhesive Vinyl/Textile* into clean, cold water (see table) and continue to stir for a few minutes. Leave for approx. 3 minutes and then stir vigorously again.

**Applying to wallpaper:**

Evenly coat the wallpaper with *decotric MC Instant Adhesive Vinyl/Textile* and fold the pasted ends together. After leaving to soften for sufficient time, hang the wallpaper with matching seams and press down.

**Applying to the surface (only textile wallpapers):**

Moisten the backside of the wallpaper widths cut to size approx 5 min. before apply to avoid blistering. Use a lambs wool roller to evenly apply the mixed *decotric MC Instant Adhesive Vinyl/Textile* to the surface over a width of 1-2 wallpaper widths. Place the wallpaper strip directly into the fresh adhesive bed and uniformly press down. Follow up the seams with a smooth seam roller after a few minutes. To increase the moisture resistance and where hanging wallpaper on hardly absorbent surfaces we recommend adding 20 % *decotric Wall Covering and Border Adhesive*. Always follow the manufacturer's instructions for use. The paste is lime- and cement constant.

Do not use if the object and/or room temperature are below + 5° Celsius!  
Remove adhesive residues using a damp cloth.  
Clean tools in water after use.

**Mixing ratio:**

for	Mixing ratio	Quantity of water per 200 g packet	Coverage of one packet
Pre-pasting	1:40	8 l	50-70 m <sup>2</sup>
Applying to wallpaper	1:20	4 l	20-25 m <sup>2</sup>
Applying to the surface	1:15	3 l	15-20 m <sup>2</sup>

**Storage:** Store in a cool and dry place!

**Available size:** 200 g collapsible box 020606001