

For perfect results

## Non-woven wallpapers

The perfectly coordinated range of **decotric** quality products makes your work easier and ensures perfect results ...

# Power Wallpapering



QUALITY  
SINCE 1928

### Cut the wallpaper strips to size prior to wall-papering

**Paste preparation:** Vigorously stir cold, clean water to create a vortex. Evenly sprinkle paste into the centre of the vortex and keep stirring briefly. Whisk again vigorously at the end of the swelling time.

**Paste application:** Apply the paste to the back of the wallpaper using the paste brush.

**Soaking:** Fold the pasted strips in a manner ensuring that the upper part is folded over for two thirds and the lower to one third. Roll the strips up to prevent their edges from coming apart and drying out.

**Pasting:** Paste the first strip to the wall in a true vertical, e.g. using a plumb line or water level. Hang the wallpaper to the wall by smoothing it out from the centre to the edges with your hands or a roller. If any paste gets on the front of the wallpaper, make sure to remove it carefully with a damp and clean cloth.

**Flush finish at skirting boards:** Cut off the excess wallpaper.

**Sockets and switches:** Switch off the power supply, remove the covers and wallpaper over the holes. Cut open the wall outlets with a carpet knife after drying.

**Ceilings:** Ceilings are best wallpapered in a team of two – one to position the wallpaper while the other holds up the rest of the strip until it has been pressed down completely.



Apply paste to the wall ...



... roll out the wallpaper ...



... and cut off.



Easily removable ...

Non-woven wallpapers are quickly gaining in popularity. They make wallpapering easier and faster than ever before.

The special benefit of non-woven wallpapers:

**The paste is applied directly onto the wall and not onto the wallpaper.** This is most easily and cleanly done with a GTV Roller.

**Advantage:** No trestle table required for pasting the paper, hands stay clean, and the application is quicker than with a paste brush.

**The wallpaper strip is not cut to size beforehand, but rolled out on the wall instead and then cut off to fit the space.**

**Advantage:** Saves time and prevents paste stains on the front of the wallpaper.

**The dry wallpaper strips are directly embedded in the paste.**

**Advantage:** No risk of the wallpaper tearing whilst attaching it, no strictly observable soaking times, cleaner cuts because dry paper cuts more easily.

**Easily removable for future redecorations.**

**Advantage:** The wallpaper can usually be easily and safely removed again without needing a wallpaper remover.

## Gluing and repairing

**Minor repairs:** The thin tube point makes decotric Wallpaper Seam Adhesive and Glutolin K-Uni-Fix ideal for fastening loose wallpaper seams on all surfaces, but it is also perfect for critical places like the seams around radiators and plastic windows, for example. Does even bond borders to vinyl wallpapers.

**Wallpaper Adhesive:** This ready-for-use adhesive for extremely heavy wallpapers even allows their attachment to non-absorbent surfaces. The adhesive can also be used as an adhesion reinforcement by adding a 750 g tin to 4 litres of prepared paste.



Art. no. 074



Art. no. 065602074



Art. no. 07



Art. no. 064501074

Art. No. 099999090-GB

2016-02

## Tools and wallpaper types

### The right paste:

Paper wallpaper	1 9
Vinyl wallpaper, textured wallpaper, embossed wallpaper, woodchip wallpaper and heavy paper wallpaper	2 3 5 8 10
Non-woven wallpaper	4 5 7
Textile and natural wallpaper	6 7 8
High-quality designer wallpaper	6 7 10
Renovation fleece and glass fibre wallpaper	6 7
Wallpapering machine	6 8 10

### The right tools:



#### Basic equipment

- 1 Trestle table
- 2 Ladder
- 3 Bucket
- 4 Paste brush
- 5 Wallpaper scissors
- 6 Carpet knife
- 7 Plumb line
- 8 Pencil
- 9 Folding rule
- 10 Seam roller
- 11 Wallpaper brush
- 12 GTV Roller

#### Premium equipment

- 1 Wallpapering/Pasting machine



## The right paste



#### 1 Power Normal Paper

- for all lightweight paper wallpapers
- ready in 20 minutes
- 5 years warranty

Art. no. 7669

- 125 g for 30–35 m<sup>2</sup>



#### 3 Power Universal Vinyl Pink-Control

- with cellulose, adhesion reinforcement and additives with application control for even application
- ready in 20 minutes
- 5 years warranty

Art. no. 022905026

- 250 g for 25–30 m<sup>2</sup>



#### 5 Power Universal Paste

- with adhesion reinforcement and modified starch
- ready in 5 minutes
- 5 years warranty

Art. no. 7699

- 500 g for 50–75 m<sup>2</sup>
- 1000 g for 100–150 m<sup>2</sup>



#### 7 Glutolin GTV

- Premium grade: with high-quality methyl cellulose, adhesion reinforcement and additives
- ready in 5 minutes
- 5 years warranty

Art. no. 390 639 01

- 200 g for 20–25 m<sup>2</sup>



#### 9 Glutolin N

- Premium grade: with high-quality methyl cellulose and additives
- ready in 20 minutes
- 5 years warranty

Art. no. 390 624 81

- 125 g for 35 m<sup>2</sup>



#### 2 Power Special Vinyl Paste

- with cellulose, adhesion reinforcement and starch
- ready in 20 minutes
- 5 years warranty

Art. no. 7679

- 200 g for 20–25 m<sup>2</sup>



#### 4 Power Vlies Non-Woven

- with cellulose, adhesion reinforcement and additives
- ready in 20 minutes
- 5 years warranty

Art. no. 7689

- 200 g for 20–25 m<sup>2</sup>



#### 6 Glutolin K10

- Premium grade: with high-quality methyl cellulose, adhesion reinforcement and additives
- ready in 20 minutes
- 5 years warranty

Art. no. 063701074  
063702074

- 500 g for 25–30 m<sup>2</sup>
- 1000 g for 50–60 m<sup>2</sup>



#### 8 Glutolin M22

- Premium grade: with high-quality methyl cellulose, adhesion reinforcement and additives
- ready in 5 minutes
- 5 years warranty
- 300 g for 30 m<sup>2</sup>
- 750 g for 75 m<sup>2</sup>

Art. no. 063201074  
063202074



#### 10 Glutolin 77

- Premium grade: with high-quality methyl cellulose, adhesion reinforcement and additives
- ready in 5 minutes
- 5 years warranty
- 200 g for 25 m<sup>2</sup>

Art. no. 390 621 81

## Surface preparation



Removing old wallpapers is much easier than imagined. decotric Wallpaper Remover easily removes even firmly stuck wallpapers. The concentrate is more effective when mixed into hot water. Richly apply the solution with a brush or a spraying device and leave to soak for approx. 15 min. Thus, the wallpaper will come off much more easily. Roughen up the surface of painted wallpapers with a needle roller beforehand.



Prior to wallpapering the surface has to be dry, clean, smooth and solid. Check the surface as follows. Spray a little water onto the wall: If the wall takes on a darker colour immediately it is too absorbent. If rubbing the wall leaves white or gray residues on the fingers, the surface is too chalky. It is essential to prime the surfaces with decotric Primer - solvent-free in both cases.



Any irregularities, holes and cracks have to be eliminated prior to wallpapering because only even surfaces allow for perfect wallpapering results. To ensure this perfect result, either use ready-mixed decotric fillers such as decofill instant or powder fillers such as decotric decofill Interior Filler.



Surfaces with low absorbency, an irregular colour or an elevated pH-value should be painted with decotric Wallpaper Primer – white prior to wallpapering. A high pH-value of the surface (pH > 11) may discolour metal, textile or natural wallpapers.



ORIGINAL  
**decotric**