

decotric Paint Brush Cleaner

Use:

Quickly and thoroughly removes fresh paint and varnish, grease, oil and tar from brushes, tools, machine parts and all solvent-resistant surfaces. Makes soiled items washable in water.

Properties:

- removes fresh paint and varnish
- removes grease, oil and tar stains
- low-odour
- lengthens service life of brushes and rollers

Technical data:

Raw material Hydrocarbons, alcohol, glycol ethers base: and non-ionic surfactants

Density: Approx. 0.81 g/cm³

Application:

Immerse brushes in decotric Paint Brush Cleaner immediately after use and properly massage bristles. Wipe off brush against side of vessel used for cleaning to remove dissolved paint residue and surplus Paint Brush Cleaner. Then rinse brush with water. Metal or machine parts must be placed in or wiped over with decotric Paint Brush Cleaner, then likewise thoroughly rinsed with water.

To clean hands and clothes (test in advance for colour fastness), rub in a few drops of decotric Paint Brush Cleaner and thoroughly rinse with water. Subsequently wash clothes by hand (not in washing machine).

Note:

Prior to use, resistance of materials to be cleaned should be tested by trial application to small area.

Please consult safety data sheet for safety-relevant data. Up-to-date safety data sheets are available from our website at www.decotric.de or from sds@decotric.de.

Medical emergency number: +49 (0)5 51/1 92 40

Storage:

Store in cool, though frost-free environment in properly sealed containers. Keep out of reach of children.

Disposal:

Hand over only fully emptied containers for recycling. Dispose of product waste under EWC waste code 14 06 03.

Item No.	EAN	Container size
005301001	4007955053019	250 ml
005306001	4007955053064	500 ml
005302001	4007955053026	1 ltr



Status: 11.05.2023

decotric GmbH, Im Schedetal 1, 34346 Hann. Münden Tel. 05541 / 7003 -02, www.decotric.de